

8-9-67  
 (Replaces  
 4-21-67 Release)

PRECISION APPARATUS  
 DIVISION of DYNASCAN CORP.  
 1801 W. Belle Plaine Ave.  
 Chicago, Ill. 60613

NEW TUBE RELEASES  
 for use with  
 TRC 1-2-67 DATA BOOK

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
1AU2		4	2	32	4	-	19	19
1AY2		4	2	20	4	-	-	0
		Insert leads into pins 4 & 9 of 9 pin socket						
2EG4		4	2	42	3	3	-	1
3AW2 (Key at 5)		4	5	15	4	-	17	0
		Cap goes to top of tube						
3BL2 (Key at 5)		4	5	28	4	-	167	0
		Cap goes to top of tube						
3BN2 (Key at 6)		5	4	21	4	-	28	0
		Lever 1 must be thrown to open position Cap goes to top of tube						
3CN3		2	5	17	4	-	35	0
3KT6		4	5	21	2	13	13	278
4AB8	Tri	4	6	25	2	3	-	12
"	Pen	4	6	22	2	-	-	689
4JH6		3	6	22	2	2	-	156
4KN8	Tri-1	4	6	20	2	8	-	67
"	Tri-2	4	6	20	2	3	-	12
4KT6		4	6	21	2	13	13	278
4M-P12		3	7	22	2	2	-	156
4M-P26		3	6	22	2	2	-	156
4R-HH8	Tri-1	4	6	20	2	8	-	67
"	Tri-2	4	6	20	2	3	-	12

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
5CR8	Tri	4	7	22	2	8	-	19
"	Pen	4	7	21	2	3	-	267
5GS7	Tri	4	8	21	2	38	38	12
"	Pen	4	8	20	2	-	-	679
6AR8	Pen-1	4	9	24	2	7	-	369
"	Pen-2	4	9	24	2	-	-	368
6BR3		4	9	18	3	0	29	●29
	●Ignore glow on 2							
6BT6	Tri	3	9	24	2	2	-	17
"	Di 1	3	9	26	3	-	-	5
"	Di 2	3	9	26	3	-	-	6
6BV11								
(Key at 7)	Pen-1	6	9	21	2	2	-	134
(Key at 2)	Pen-2	1	9	21	2	7	-	568
6BY11								
(Key at 0)	Pen-1	1	9	21	2	2	-	3567
(Key at 8)	Pen-2	7	9	21	2	4	-	356
6CH3		4	9	20	2	9	27	●27
	●Ignore glow on 2							
6CL3		4	9	20	2	9	27	●27
	●Ignore glow on 2							
6CR8	Tri	4	9	22	2	8	-	19
"	Pen	4	9	21	2	3	-	267
6DR4		3	9	24	2	7	15	●156
	●Ignore glow on 1							
6EC4*		4	9	20	2	0	278	●278
	●Ignore glow on 27							
	Cap goes to top of tube							
	*Magnoval base - Do not insert tube fully into socket							
6ED4*		4	9	32	2	1	123679	80
	*Magnoval base - Do not insert tube fully into socket							
	Cap goes to top of tube							
6G-B7		2	9	4	1	8	-	450
6G-K17		7	9	22	2	3	-	5

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
6KN8	Tri-1	4	9	20	2	8	-	67
"	Tri-2	4	9	20	2	3	-	12
6KT6		4	9	21	2	13	13	278
6LB6 (Key at 4)		3	9	21	2	6	1278	●2790
	●Ignore glow on 2 Cap goes to top of tube							
6LC6		2	9	35	2	6	134	50
6MF8 (Key at 8)	Pen	9	9	22	2	4	12	●1230
	●Ignore glow on 1							
(Key at 5)	Tri	6	9	21	2	3	-	27
6MK8	Pen-1	4	9	22	2	1	-	237
"	Pen-2	4	9	22	2			278
6R3		4	9	22	2	0	*	29
	*May show short on all pins							
6R4		4	9	23	2	3	-	18
6R-HH8	Tri-1	4	9	20	2	8	-	67
"	Tri-2	4	9	20	2	3	-	12
6R-P22		4	9	20	2	1	2389	●236
	Throw levers 8-9 to open position ●Ignore glow on 2							
8BQ7	Tri-1	4	10	24	2	8	-	67
"	Tri-2	4	10	24	2	3	-	12
8GU7	Tri-1	4	11	24	2	8	-	67
"	Tri-2	4	11	24	2	3	-	12
8R-HP1	Tri	4	10	25	2	8	-	19
"	Pen	4	10	23	2	2	-	367
9ED4*		4	10	32	2	1	123679	80
	Cap goes to top of tube *Magnoval base - Do not insert tube fully into socket							
9GH8	Tri	4	12	22	2	8	-	19
"	Pen	4	12	22	2	7	-	2-3-6

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
9R-AL1	Tri-1	4	11	25	2	8	23	67
"	Tri-2	4	11	21	2	9	-	●123
	●Ignore glow on 2							
9R-HR2	Tri	4	12	22	2	8	-	19
"	Pen	4	12	22	2	7	-	236
11HM7		6	8	20	2	1	3459	278
12B-B14*		4	13	20	2	38	123678	●12670
	●Ignore glow on 16							
	*Magneval base - Do not insert tube fully into socket							
	Cap goes to top of tube							
12BR3		4	13	18	3	0	29	●29
	●Ignore glow on 2							
12BV11								
(Key at 7)	Pen-1	6	13	21	2	2	-	134
(Key at 2)	Pen-2	1	13	21	2	7	-	568
12CL3		4	9	20	2	9	27	●27
	●Ignore glow on 2							
12FQ7	Tri-1	4	13	7	1	8	-	67
"	Tri-2	4	13	7	1	3	-	12
12G11								
(Key at 6)	Pen-1	7	13	23	2	2	-	134
(Key at 2)	Pen-2	1	13	25	2	4	-	5689
12G-K17		7	13	7	1	3	-	5
12R-LL5	Tri-1	4	13	7	1	8	-	67
"	Tri-2	4	13	7	1	3	-	12
17B-B14*		4	15	20	2	38	123678	●12670
	●Ignore glow on 16							
	*Magneval base - Do not insert tube fully into socket							
	Cap goes to top of tube							
17CL3		4	14	20	2	9	27	●27
	●Ignore glow on 2							
17DW4		4	15	4	1	9	27	2
	Lever 7 must be thrown to open position							
20AQ3		4	16	23	2	0	*	●389
	●Ignore glow on 38 *Cont test - 1236789							

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
22KM6		4	17	21	2	3	1267	670
		Throw levers - 1-2 to open position Cap goes to top of tube						
29KQ6*		4	19	20	2	9	123678	●130
		Levers 6-8 must be thrown to open position ●Ignore glow on 1 Cap goes to top of tube *Magneval base - Do not insert tube fully into socket						
30KD6 (Key at 4)		3	19	20	2	6	1278	●2790
		●Ignore glow on 2 Cap goes to top of tube						
7320		4	9	5	1	3	12	●1279
		●Ignore glow on 1						
7788		4	9	19	2	13	1369	2679
<u>FOREIGN</u>								
EAF-801	Di	3	9	21	4	3	-	8
"	Pen	2	9	21	4	-	-	126
ED-500*		4	9	32	2	1	123679	80
		Cap goes to top of tube *Magneval base - Do not insert tube fully into socket						
EF-804		4	9	23	2	3	26	789
EY-500*		4	9	20	2	0	278	●278
		●Ignore glow on 27 Cap goes to top of tube *Magneval base - Do not insert tube fully into socket						
LCF-80	Tri	4	9	23	2	8	-	19
"	Pen	4	9	22	2	7	-	236
LF-183		4	6	22	2	13	13	2789
LF-184		4	6	21	2	13	13	2789
PD-500*		4	10	32	2	1	123679	80
		Cap goes to top of tube *Magneval base - Do not insert tube fully into socket						

TUBE	SECT	A	B	C	D	CATH	CONT	TEST
PL-521*		4	19	20	2	9	123678	●130

Levers 6-8 must be thrown to open position

●Ignore glow on 1

Cap goes to top of tube

\*Magnoval base - Do not insert tube fully into socket

CORRECTION

2AS2

(Key at 5)

		4	4	27	4	-	17	0
--	--	---	---	----	---	---	----	---

Cap goes to top of tube